



Installation Procedures

Remove trim/diffuser from bulkhead housing.

Push on ends of screws to release fibre washers.
NOTE: Fibre washers can be re-used to facilitate fitting grille or hood.

Fit grille or hood to trim/diffuser using supplied screws (A), nylon washers (B) and fibre washers (C).

Fit assembly to bulkhead housing.

