



Installation

Mechanical Structure & Dimensions


1




1. Fix the spring-mount box (with junction box)



1. Fix the spring-mount box (without junction box)



2




2. Fix cables

3

3. Install the sensor into the spring-mount box




4




4. Rotate the sensor counter-clockwise till the end to tighten up

5




5. Finished (with junction box)



5. Finished (without junction box)

Big and small silicon gasket used to make IP54 degree protection when mounted into HA03 housing for ceiling mount

Small silicon water-proof gasket dimension(size:mm)



Big silicon water-proof gasket dimension(size:mm)

