

MONO: 3035901 3035902 3035903 3035904 3035921 3035922 3035923 3035924
 DUO: 3035905 3035906 3035909 3035910 3035925 3035926 3035929 3035930
 TRIO: 3035911 3035912 3035913 3035914 3035921 3035922 3035923 3035924
 ROUND: 3035935 3035936 3035937 3035938

Isolate from the mains supply before any maintenance.


Vor Wartungsarbeiten von der Netzspannung trennen.

Veillez isoler le luminaire du courant avant toute maintenance.

Aislar de la red eléctrica antes de cualquier operación de mantenimiento.

Koppel het toestel af van de netspanning voor elk onderhoud.

Isolera från elnätet innan något underhåll.



Switch Off








Abschalten

Débrancher

Desconectar

Uitschakelen

Stäng av



Suitable for use indoors
 Geeignet für Innenanwendung
 Pour un usage interne

Adecuada para uso en interiores
 Geschikt voor gebruik binnen
 Lämpig för inomhusbruk

